

Wireless RF Homcloud Door&Window detector

Features

Wireless Door & Window detector adopt best technology to prevent false alarms Built-in RF frequency antenna, longer launch distance, environmental saving, reliable, easy to install, support low battery remind function and so on.

Homcloud code: WL-RFDS

Model n°: WL-19DW

Pilot lamp

LED lamp flash one time: alarm

Installation

Installation location need to be clean and smooth. Place them on border of door/window you want to control. Fix with bi-adhesive both magnetic part of the sensor. Distance between two parts need to be around 1cm

Don't install two detectors in same place to avoid interference with each other.

Test

A. Finished installing, check the batteries are charged, bring the two parts of the sensor closer together until led blinks.

Configuration

1. (recommended) For the complete configuration of the sensors read the manual of the Homcloud Alarm Controller.

When you have inserted the batteries and the sensor has the LED light on, enter the App in the Homcloud Alarm Control Unit already configured and select the "Add Detectors / Sensors" section, then subsequently:

Method A: Move the two magnetic parts of the sensor closer and further away from each other

The LED light will flash again, a beep will sound (control unit) and the sensor will appear on the App ready to be positioned within a zone or room.

Technical parameters

Power: 3V Lithium Battery 2*AAA

Standby Current: ≤25uA

Alarm current: ≤20mA

Detection range: 1 cm

Wireless distance: ≤150m in open area

Frequency: $433 \text{mhz} \pm 75 \text{khz}$

Material: ABS plastic

Working humidity: ≤80% (No condensation)

More info www.homcloud.com

Imported by: Life365 Italy S.p.A. - European General Agency

Viale Roma 49/a, 47122 Forlì, Italy - Made in China





